

# GT-530 FAQ

# Tables of Content

<b>Q01 : EXT LED is off without Li-battery .....</b>	<b>3</b>
<b>Q02 : STA is always on .....</b>	<b>3</b>
<b>Q03 : GT-530 Utility can not connect to GT-530 .....</b>	<b>3</b>
<b>Q04 : After event triggering, users can not receive SMS.....</b>	<b>3</b>
<b>Q05 : Counter value is abnormal .....</b>	<b>3</b>
<b>Q06 : The content of received SMS is abnormal. ....</b>	<b>3</b>
<b>Q07 : The time of receiving SMS is abnormal.....</b>	<b>3</b>
<b>Q08 : STA led is blanking per 50 ms.....</b>	<b>4</b>
<b>Q09 : Forget Password .....</b>	<b>4</b>
<b>Q10 : If the GT-530 can not send a SMS, how does user do? .....</b>	<b>4</b>
<b>Q11 : SMS DBS could not received the SMS from GT-530. ....</b>	<b>4</b>
<b>Q12 : How many maximum value of counter does the GT-530 support? .....</b>	<b>4</b>
<b>Q13 : How long does Li-Battery supply power to GT-530?.....</b>	<b>4</b>
<b>Q14 : What is the GT-530 default login password? .....</b>	<b>4</b>
<b>Q15 : What is the input impedance of the DI channels? .....</b>	<b>4</b>
<b>Q16 : Is it possible to send SMS using the RS-232 interface? .....</b>	<b>4</b>
<b>Q17 : How to send SMS by COM3?.....</b>	<b>4</b>

**Q01 : EXT LED is off without Li-battery**

A01 : Please check the external power and wire connection.

**Q02 : STA is always on**

A02 :

Check SIM card

Check Antenn

Check the GSM signal strength

**Q03 : GT-530 Utility can not connect to GT-530**

A03 : Check STA LED blinking every 1 sec

Check com port connection and baud rate setting

**Q04 : After event triggering, users can not receive SMS.**

A04 :

Check DI connection

Check phone number and format

Check DI event is enabled in GT-530 Utility

**Q05 : Counter value is abnormal**

A05 :

Check wire connection

Check the counter signal is at 5~40Hz.

Check the DI mode setting. Must be counter mode.

**Q06 : The content of received SMS is abnormal.**

A06 : Please select the correct language to set the content of SMS in utility. If you want to transfer Unicode char, select the language supporting UCS2.

**Q07 : The time of receiving SMS is abnormal.**

A07 :

1. The time in GT-530 is abnormal. Setup the time of GT-530 by utility.
2. The battery of RTC is low. Change the silver battery of RTC. After changing the battery, set the time of GT-530.

**Q08 : STA led is blanking per 50 ms**

A08 : The pin code is wrong. The login windows would show the field to input PIN or PUK code

**Q09 : Forget Password**

A09 : Use SMS command to get the password.

**Q10 : If the GT-530 can not send a SMS, how does user do?**

A10 : Please install the SIM card on the user's cell phone and try to send a SMS in order to check the SMS function of the SIM Card that is enabled.

**Q11 : SMS DBS could not received the SMS from GT-530.**

A11 : User must add "ALARM;" to the start of the short message.

**Q12 : How many maximum value of counter does the GT-530 support?**

A12 : The maximum counter value is 999999999.

**Q13 : How long does Li-Battery supply power to GT-530?**

A13 : A new 1200mAh Li-Battery can supply power to GT-530 for 36 hours without the external power. The power volume of Li-Battery would be decreasing for a long time. It is recommended to change the Li-Battery every 6 months.

**Q14 : What is the GT-530 default login password?**

A14 : The default login password is "111111".

**Q15 : What is the input impedance of the DI channels?**

A15 : GT-530 with TTL / CMOS logic circuit, it doesn't consider the input impedance.

**Q16 : Is it possible to send SMS using the RS-232 interface?**

A16 : GT-530 provides sending/receiving SMS from COM3(RS-232).

**Q17 : How to send SMS by COM3?**

A17 : GT-530 can send SMS to the first setting phone number by command header "+++".

Example:

Command from COM3 : +++Hello

Cell phone received SMS content : Hello